

# **Supplement 1/61 to Spare Parts List Type 3**

## **New parts:**

311 101 463	Nut, hex.
311 107 331 A	Scraper ring
343 251 285	Exhaust tail pipe trim
311 255 509 B	Heater pipe
311 401 021	Front axle beam
311 401 319 B	Thrust ring
311 401 319 C	Thrust ring
311 405 345	Stop – Steering knuckle
311 405 346	Stop – Steering knuckle
113 611 057 B	Cylinder – Rear wheel brake
311 711 115 0M	Rubber boot satin blue
311 711 115 0A	Rubber boot malachite green
311 711 327	Handle
311 711 337	Retainer
311 821 805	1 set of mud flaps
311 845 101 A	Glass – Windshield laminated
311 905 443	Cap (rubber)
341 919 199	Clock
311 941 037	Retaining clip
312 941 039	Headlamp
312 941 115	Lens
311 941 141 A	Adjusting screw
311 941 145	Threaded piece
312 941 151	Reflector – Headlamp
311 941 175	Rim
311 945 235	Gasket
311 951 115	High note horn
311 953 161 A	Lens
N 10 071 1	Screw, hex. head
N 13 969 1	Tapping screw, fillister head

**VOLKSWAGENWERK AKTIENGESELLSCHAFT · WOLFSBURG**

## **No longer available:**

311 107 331	superseded by: 311 107 331 A
311 209 147	superseded by: 111 209 147 A
311 255 509	superseded by: 311 255 509 B
311 401 025	superseded by: 311 401 021
311 401 319	superseded by: 311 401 319 B
311 401 319 A	superseded by: 311 401 319 C
113 517 145 A	superseded by: 113 517 145
113 611 057 A	superseded by: 113 611 057 B
311 711 319	superseded by: 311 711 327/337
343 919 199	superseded by: 341 919 199
N 13 966 1	superseded by: N 13 968 1, N 13 969 1
N 14 138 1	superseded by: N 10 715 2

## **Delete:**

311 853 101	no longer available
311 853 111	no longer available

# **Supplement 2/61**

## **to Spare Parts List Type 3**

### **New parts:**

311 119 293 B	Strap	113 611 363	Plug
311 119 681	Rubber packing	361 611 607	Cup expander
311 129 581 B	Elbow	361 611 639	Cup
311 129 591	Clip	361 611 655	Piston
311 129 597	Retainer	361 611 693	Circlip
311 129 609 B	Control box	361 611 695	Boot
311 129 611 B	Air cleaner	312 611 741	Brake line (RHD)
312 201 055	Fuel tank (RHD)	312 611 805	Line (RHD)
311 255 105	Heat exchanger	312 700 021	Frame (RHD)
311 255 106	Heat exchanger	361 700 021	Frame
311 255 219	Gasket	362 700 021	Frame (RHD)
312 259 305	Fresh air control (RHD)	361 700 041	Sub-frame
111 301 289 B	Gasket	312 705 057	Floor plate (RHD)
312 400 025	Front axle (RHD)	312 705 058	Floor plate (RHD)
342 400 025	Front axle (RHD)	361 705 481	Kick plate
312 401 021	Front axle beam (RHD)	311 705 761	Rubber washer
361 411 309	Stabilizer	311 707 031 B	Bumper
311 415 270	Shim	311 711 175	Coupling-Gearshift rod
312 415 371	Steering drop arm (RHD)	312 721 121	Shaft (RHD)
342 415 371	Steering drop arm (RHD)	312 721 127	Bush (RHD)
341 415 565	Tube – Steering column	312 721 137	Bush (RHD)
312 415 801	Tie rod (RHD)	312 721 141	Pedal-Brake (RHD)
312 415 802	Tie rod (RHD)	311 721 153	Bush
311 415 901 A	Steering damper	312 721 163	Return spring (RHD)
361 501 067	Rear axle tube	312 721 241	Bracket (RHD)
361 501 068	Rear axle tube	312 721 315	Pedal-Clutch (RHD)
361 501 191	Rubber stop	312 721 545	Accelerator pedal shaft (RHD)
311 501 201 AB	Rear axle shaft	312 721 587	Cover plate (RHD)
311 501 201 AR	Rear axle shaft	312 721 591	Seal (RHD)
361 511 115	Torsion bar	312 721 671	Foot support (RHD)
361 511 116	Torsion bar	312 721 672	Foot support (RHD)
113 517 167 F	Thrust washer	312 800 101	Body (RHD)
113 517 167 G	Thrust washer	361 800 101	Body
311 609 631	Push bar	362 800 101	Body (RHD)
361 611 069	Cylinder – Front wheel brake	312 800 401	Body bare (RHD)
113 611 301 D	Reservoir	361 800 401	Body bare
113 611 351	Screw cap	362 800 401	Body bare (RHD)

312 805 051	Instrument panel (RHD)	361 827 025	Rear door
311 805 141	Screw fillister head	361 827 185	Adjustment plate
311 805 149	Tapping screw	361 827 195	Guide piece
312 805 441	Cross panel (RHD)	361 827 301	Hinge
361 809 029	Quarter panel	361 827 302	Hinge
361 809 030	Quarter panel	361 827 325	Bolt
311 809 493 A	Cover	361 827 361	Hinge stay
361 809 557	Bow-Roof	361 827 375	Torsion bar
361 809 559	Bow-Roof	361 827 376	Torsion bar
361 809 601	Quarter panel	361 827 399	Bolt
361 809 602	Quarter panel	361 827 499	Rubber stop
361 809 805 A	End plate	361 827 505	Lock
361 809 806 A	End plate	361 827 511	Striker plate
361 809 809	Cover	361 827 527	Weatherstrip
361 809 810	Cover	361 827 529	Cover plate
361 813 073	Support	361 827 539	Press button
361 813 074	Support	361 827 705	Weatherstrip
361 813 111	Floorplate-Luggage compartment	361 827 715	Weatherstrip
311 813 115	Floorplate-Luggage compartment	312 831 051	Door bare (RHD)
361 813 151	Cover plate-Engine	312 831 052	Door bare (RHD)
361 813 301	Rear apron	111 837 507	Spring
361 813 373 A	Water drain flap	311 837 565 A	Weatherstrip
361 813 417	Extension	111 837 571 D	Lift channel – Door window
361 813 418	Extension	111 837 572 D	Lift channel – Door window
311 813 789 A	Catch	312 845 101	Glass – Windshield (RHD)
361 817 021	Roof	361 845 301 A	Glass – Quarter window
361 817 357	Hinge mounting	361 845 321	Weatherstrip
361 817 358	Hinge mounting	361 845 322	Weatherstrip
361 817 363	Cross member	361 845 331	Glass – Quarter window
361 817 371	Bow-Roof	361 845 341	Weatherstrip
361 817 381	Cross member	361 845 342	Weatherstrip
311 821 021 A	Fender	361 845 501	Glass – Rear window
311 821 022 A	Fender	361 845 521	Weatherstrip
361 821 301	Fender	312 853 191	Molding (RHD)
361 821 302	Fender	312 853 192	Molding (RHD)
361 821 333	Weatherstrip	361 853 345	Trim frame
361 821 334	Weatherstrip	361 853 346	Trim frame
311 821 705 A	Beading	361 853 347	Trim frame
311 821 706 A	Beading	361 853 348	Trim frame
311 821 715 A	Beading	361 853 349	Sleeve
361 821 715	Beading	361 853 355	Trim frame, half
311 821 716 A	Beading	361 853 356	Trim frame, half
361 821 716	Beading	311 853 691	Name "1500"
361 821 781	Beading	361 853 691	Name
361 821 782	Beading	311 853 693	Seal
343 823 531	Cable – Front hood lock	311 853 695 A	Clamping plate

312 857 051	Instrument panel cover (RHD)	361 885 537	Eye
312 857 101	Glove compartment (RHD)	361 885 549	Handle
312 857 121	Lid – Glove compartment (RHD)	361 885 579	Spring
312 857 502	Rear view mirror (RHD)	361 885 753	Rubber lining
312 863 024	Lining – Front panel (RHD)	361 885 805	Padding
312 863 107	Lining – Front panel (RHD)	311 905 851 A	Steering-ignition lock
361 863 465	Rubber lining	311 905 871	Cap
312 863 703 A	Mat – Floor (RHD)	341 919 305	Cigar lighter
361 863 881 A	Lining	311 937 505	Fuse box
361 863 882 A	Lining	311 941 041	Retaining clip
361 863 891	Sound absorber	361 943 117	Bulb holder
361 863 893	Sound absorber	361 943 121	Lens
311 867 013 A	Trim panel – Door	311 943 149	Bracket
311 867 014 A	Trim panel – Door	361 943 191	Gasket
361 867 037	Trim panel – Quarter panel	311 945 241 A	Lens red
361 867 038	Trim panel – Quarter panel	311 951 111 A	Interior
361 867 285	Padded strip	311 953 053	Bulb holder
361 867 286	Padded strip	311 953 054	Bulb holder
361 867 341	Arm rest	312 971 011	Main harness (RHD)
361 867 342	Arm rest	361 971 011	Main harness
361 867 421	Lining – Luggage compartment	362 971 011	Main harness (RHD)
361 867 422	Lining – Luggage compartment	312 971 075	Harness (RHD)
361 867 425	Rubber cap	311 971 077	Harness
361 867 433	Corner lining	N 10 244 1	Bolt, hex. head
361 867 434	Corner lining	N 10 249 1	Bolt, hex. head
361 867 501	Lining – Roof	N 10 355 1	Bolt, hex. head
361 867 527	Covering plate	N 11 132 2	Nut, hex.
361 867 601	Trim panel	N 11 367 2	Tapping screw, cheese head
361 867 615	Clip	N 11 466 3	Tapping screw, countersunk raised head
311 867 935	Insulation	N 11 975 1	Screw, fillister head
361 885 031	Seat rear	N 12 408 1	Lockring
361 885 041	Seat back, rear	N 12 418 1	Lockring
361 885 061	Rear panel	N 12 436 2	Lock washer
361 885 331	Cap	N 12 455 1	Circlip
361 885 341	Support	N 13 890 1	Tapping screw, hex head
361 885 405	Cover	N 14 227 1	Screw, countersunk head
361 885 441	Trim panel	N 14 228 1	Screw, countersunk head
361 885 449	Clip	N 30 057 1	Wrench
361 885 533 A	Beading	SP 340	1 set of cover plates

## No longer available:

311 119 293 A Superseded by: 311 119 293 B/N 14 395 2  
311 129 575 Superseded by: 311 129 581 B/591/597  
311 129 609 Superseded by: 311 129 609 B  
311 129 611 Superseded by: 311 129 611 B  
311 255 105 A Superseded by: 311 255 105  
311 255 106 A Superseded by: 311 255 106  
311 809 493 no longer available  
311 813 789 Superseded by: 311 813 789 A  
311 821 705 Superseded by: 311 821 705 A  
311 821 706 Superseded by: 311 821 706 A  
311 821 715 Superseded by: 311 821 715 A  
311 821 716 Superseded by: 311 821 716 A  
311 823 531 A Superseded by: 343 823 531  
311 837 507 Superseded by: 111 837 507  
311 847 146 B Superseded by: 311 847 145 B  
311 863 893 Superseded by: 361 863 893  
311 867 013 Superseded by: 311 867 013 A  
311 867 014 Superseded by: 311 867 014 A  
311 905 851 Superseded by: 311 905 851 A  
311 937 035 Superseded by: 311 937 505  
311 941 037 Superseded by: 311 941 041  
311 941 141 Superseded by: 211 941 141

# **Supplement 3/62 to Spare Parts List Type 3**

## **New parts:**

113 109 309 B	Cam follower
311 129 109 A	Cover – Carburetor
311 129 327	Injector tube
311 129 417 A	Cap
311 129 421	Pilot jet
311 129 449	Spacer washer
311 129 451 A	Diaphragm
311 129 479	Pin
311 129 481 A	Throttle connector rod
311 129 489	Lock spring
311 311 307	Clutch gear
311 611 021 A	Brake master cylinder
311 611 061 A	Cylinder
311 611 062 A	Cylinder
311 611 143 A	Piston return spring
311 611 165 B	Piston
312 721 555	Cable – Accelerator (RHD)
311 821 705 A	Beading 039
311 821 706 A	Beading 039
311 821 715 A	Beading 039
361 821 715 A	Beading
311 821 716 A	Beading 039
361 821 716 A	Beading
361 821 781	Beading 039
361 857 507	Rear view mirror
311 885 031 A	Seat
311 885 039 B	Seat back
311 885 041	Seat back
361 885 051	Seat back
361 885 533 B	Beading
311 885 705	Spring core
311 885 775	Padding
311 885 805	Cover
311 885 805 C	Cover
311 885 851 B	Cover
111 019 711 A	Safety belt
311 040 151	1 set of rim embellishers
311 040 153	1 set of rim embellishers
311 040 155	1 set of rim embellishers
311 040 157	1 set of rim embellishers
SP 150	Repair kit for wheel brake cylinder

**VOLKSWAGENWERK AKTIENGESELLSCHAFT · WOLFSBURG**

## No longer available:

113 105 271 A Superseded by: 113 105 271 B  
311 109 019 Superseded by: 113 109 019 B  
311 109 021 Superseded by: 113 109 021 B  
311 109 023 Superseded by: 113 109 023 B  
311 109 025 Superseded by: 113 109 025 B  
311 109 027 Superseded by: 113 109 027 B  
311 109 029 Superseded by: 113 109 029 B  
311 109 031 Superseded by: 113 109 031 B  
311 109 033 Superseded by: 113 109 033 B  
311 109 035 Superseded by: 113 109 035 B  
113 109 309 A Superseded by: 113 109 309 B  
311 129 109 Superseded by: 311 129 109 A  
311 129 419 No longer available  
113 611 301 D Superseded by: 113 611 301 B  
113 611 313 A Superseded by: 113 611 301 B  
361 611 695 Superseded by: 113 611 695 E  
361 821 715 Superseded by: 361 821 715 A  
361 821 716 Superseded by: 361 821 716 A  
361 821 782 Superseded by: 361 821 781  
311 867 615 Superseded by: 361 867 615  
311 885 031 Superseded by: 311 885 031 A  
311 885 039 A Superseded by: 311 885 039 B  
361 885 041 Superseded by: 361 885 051  
361 885 533 A Superseded by: 361 885 533 B  
311 885 805 B Superseded by: 311 885 805 C  
311 885 851 A Superseded by: 311 885 851 B



# **Supplement 4/62**

## **to Spare Parts List Type 3**

### **New parts:**

113 127 117 A	Fuel pump rocker arm (one-piece) (see Workshop Bulletin)	
113 127 131 A	Return spring (for 113 127 117 A)	
311 255 103	Heat exchanger	
311 255 104	Heat exchanger (with sprayed-on insulation)	
361 813 251	Retaining strap	
311 813 327 A	Extension	
311 813 328 A	Extension (to simplify repairs)	
311 863 021	Lining – Front panel	426
311 863 022	Lining – Front panel	426
312 863 022	Lining – Front panel (RHD) (with side member mat)	426
361 863 883	Sound absorber front	
361 863 884	Sound absorber front	
361 863 885	Sound absorber rear	
361 863 886	Sound absorber rear (now available as spare part)	
313 867 503	Lining – Roof	374
313 867 549	Retaining spring (for sliding roof Sedans)	
311 881 223	Arm	
311 881 247	Clip	
311 881 251	Fingerpull (now available as spare part)	
K 374 13 B	Leatherette (now available as spare part)	
311 885 305 A	Spring core	
361 885 305	Spring core	
361 885 375	Padding	
361 885 533 C	Beading	
361 885 569	Pivot rod	
361 885 570	Pivot rod	
361 885 593	Cover plate	
311 885 705 C	Spring core	
361 885 705	Spring core	
361 885 775	Padding (now available as spare part)	

## No longer available:

311 209 185      superseded by: 211 209 187  
311 255 105      superseded by: 311 255 103  
311 255 106      superseded by: 311 255 104  
311 255 357 A    superseded by: 311 255 355 A  
311 255 358 A    superseded by: 311 255 356 A  
311 821 141      superseded by: N 10 216 2  
361 821 334      superseded by: 361 821 333  
361 827 499      no longer available  
312 845 101      superseded by: 311 845 101  
311 863 023      superseded by: 311 863 021  
311 863 024      superseded by: 311 863 022  
312 863 024      superseded by: 312 863 022  
311 885 305      superseded by: 311 885 305 A  
361 885 533 B    superseded by: 361 885 533 C  
311 885 705 B    superseded by: 311 885 705 C

## Delete:

311 700 041      superseded by: 361 700 041

# **Supplement 5/62**

## **to Spare Parts List Type 3**

### **New parts:**

113 105 531 D	Bearing shell (oval bearing)
311 119 105 E	Fan (Improvement)
311 129 123	Screw, cheese head (Correction)
311 259 175 B	Cable 477 mm
311 259 176 B	Cable 280 mm
311 259 178 B	Cable 272 mm
311 259 325	Clip
311 259 379 A	Button
311 259 380 A	Button
311 259 383 B	Button (see Workshop Bulletin)
113 311 247 A	Synchronizer stop ring
113 311 295 A	Synchronizer stop ring (see Workshop Bulletin)
111 501 281 A	Spacer (see Workshop Bulletin)
311 837 521	Cap (new part)
311 847 101 A	Frame – Quarter window
311 847 102 A	Frame – Quarter window
311 847 135 C	Beading – Quarter window
311 847 137	Weatherstrip 1880 mm (see Technical Bulletin)
361 853 687	Name
361 853 689	Name
361 853 691 A	Name
311 853 693 A	Seal
311 853 695 C	Clamping plate (new parts)
N 12 131 2	Shake-proof washer
N 12 545 2	Cotter pin
N 13 074 1	Stud
N 14 451 2	Stud
N 14 501 1	Stud (new parts)
SP 29 F 0	1 set of crankshaft bearings (oval bearing)
SP 191	1 set of tumblers (Correction)
LKL 140	Standard primer
LKL 145	Filler
L 146	Universal filler (Improvement)
D 2	Sealing compound (in tubes)

## Section 2

343 259 103 A	Fresh air control box
343 259 104 A	Fresh air control box (Improvement)
343 831 731	Weatherstrip
343 831 732	Weatherstrip (Correction)
343 837 195	Guide – Pull rod (Improvement)
343 847 349 A	Cap (Improvement)
343 857 687 A	Cover strip (Improvement)

## No longer available:

311 119 105 C	Superseded by: 311 119 105 E
311 129 283	Superseded by: N 11 523 3
311 259 147	No longer available
311 259 383 A	Superseded by: 311 259 383 B
311 847 101	Superseded by: 311 847 101 A
311 847 102	Superseded by: 311 847 102 A
361 853 691	Superseded by: 361 853 691 A
311 853 695 A	Superseded by: 311 853 695 C
311 955 111	Superseded by: 341 955 111
N 13 042 2	Superseded by: N 13 074 1

## Section 2

343 259 103	Superseded by: 343 259 103 A
343 259 104	Superseded by: 343 259 104 A
343 847 349	Superseded by: 343 847 349 A
343 847 350	Superseded by: 343 847 349 A

## Delete:

311 129 451	Superseded by: 311 129 451 A
311 415 901 B	Superseded by: 311 415 901 A
311 511 205	Superseded by: 111 511 205 A

# **Supplement 6/62**

## **to Spare Parts List Type 3**

### **New parts:**

311 129 511	Adapter pipe (see Workshop Bulletin)
311 129 561	Retainer – Elbow (change in production)
311 129 767 A	Lever – Relay shaft (see Workshop Bulletin)
311 129 773 A	Link (change in production)
311 611 701 A	Hose – Front brake
311 611 723 A	Brake line front
311 611 724 A	Brake line front (see Workshop Bulletin)
311 721 509	Lever – Accelerator cable connecting
312 721 545 A	Accelerator pedal shaft (RHD)
311 721 551 A	Protective tube (see Workshop Bulletin)
313 800 101	Body, finished
314 800 101	Body, finished (RHD)
313 800 401	Body bare
314 800 401	Body bare (RHD) (new parts)
313 809 029	Quarter panel
313 809 030	Quarter panel (new parts)
313 809 667 A	Water drain pipe
313 809 668 A	Water drain pipe (new parts)
313 817 021	Sliding roof
313 817 133	Cross member (new parts)
361 821 805	1 set of mud flaps
311 831 155	Threaded plate (now available as spare part)
361 885 449 A	Clip (change in production)
313 877 071	Sliding roof panel
313 877 205 A	Plug rear – Sliding roof panel
313 877 209	Weatherstrip (foam rubber), rear
313 877 213 B	Weatherstrip, rear
313 877 217	Threaded plate M 32×1
313 877 223 B	Weatherstrip, front
313 877 227	Beading, side
313 877 231	Water drain hose, front
313 877 233	Water drain hose, rear
313 877 259	Frame – Roof panel lining
313 877 281	Clip – Frame
313 877 305	Guide rear left
313 877 306	Guide rear right

313 877 355 Guide rail, left  
 313 877 356 Guide rail, right  
 313 877 359 Retainer – Guide rail  
 313 877 363 Cable channel, lower part  
 313 877 364 Cable channel, lower part  
 313 877 365 Cable channel, upper part  
 313 877 366 Cable channel, upper part  
 313 877 369 Guide housing  
 313 877 371 Tensioning plate – Guide housing  
 313 877 375 Cover – Guide housing  
 313 877 403 Winding gear  
 313 877 407 Pinion – Winding gear  
 313 877 411 Packing – Finger plate  
 313 877 415 A Rubber strip, front  
 313 877 433 Finger plate  
 313 877 453 Winder  
 313 877 465 Escutcheon – Winding gear  
 313 877 471 Screw – Winder  
 313 877 481 Guide, front  
 313 877 495 Knurled nut M 32×1  
 (new parts)  
 111 903 515 A Carbon brush  
 (improvement in quality)  
 311 941 511 A Press button switch  
 311 941 581 A Relay  
 (see Workshop Bulletin)  
 341 957 375 Seal  
 N 12 405 1 Lockring  
 N 14 131 2 Screw, fillister head  
 N 14 138 1 Screw, fillister head  
 N 14 212 1 Screw, countersunk head  
 N 15 422 1 Speed nut  
 (now available as spare part)

#### Section 2

343 805 051 A Instrument panel  
 343 805 451 A Cross panel  
 343 857 061 A Padded strip  
 (see Workshop Bulletin)

#### No longer available:

311 129 773 superseded by: 311 129 773 A  
 361 885 449 superseded by: 361 885 449 A

#### Section 2

344 800 101 will not be introduced  
 344 800 401 will not be introduced  
 344 805 051 will not be introduced  
 344 805 451 will not be introduced  
 343 847 351 no longer available  
 343 847 352 no longer available  
 344 857 061 will not be introduced  
 344 857 101 will not be introduced  
 344 857 121 will not be introduced

#### Delete:

311 255 359 superseded by: 113 255 359  
 311 721 173 superseded by: 111 721 173  
 N 12 102 2 superseded by: N 12 131 2      Section 2

# **Supplement 7/62**

## **to Spare Parts List Type 3**

### **New parts:**

311 107 101 CB	Piston 83 mm dia.
311 107 101 CR	Piston 83 mm dia.
311 107 101 CG	Piston 83 mm dia. (Improvement)
311 107 333 A	Expander spring (change in production)
113 109 019 D	Camshaft with timing gear
113 109 021 D	Camshaft with timing gear
113 109 023 D	Camshaft with timing gear
113 109 025 D	Camshaft with timing gear
113 109 027 D	Camshaft with timing gear
113 109 029 D	Camshaft with timing gear
113 109 031 D	Camshaft with timing gear
113 109 033 D	Camshaft with timing gear
113 109 035 D	Camshaft with timing gear
113 109 309 C	Cam follower (see Workshop Bulletin)
113 109 621	Cap (New part)
113 109 623 A	Spring – Valve (see Workshop Bulletin)
311 115 451 C	Oil breather
311 115 525 A	Washer
311 115 529 A	Filter (Improvement)
341 115 621	Protection cap
341 115 623	Protection ring (New parts)
311 129 701	Intake manifold (alteration of part No.)
111 141 719 B	Clutch operating lever
311 255 509 A	Heater pipe
311 255 513 A	Heater pipe (change in production)
311 311 307 A	Clutch gear (see Workshop Bulletin)
113 311 581 A	Reverse lever (change in production)
141 415 851 B	Lock plate (to simplify repairs)
113 611 301 F	Reservoir (Improvement)
311 701 449	Threaded plate (for M 259)

341 711 121	Gearshift lever (New part)
361 817 209	Rain drip channel
361 817 210	Rain drip channel
311 817 211	Rain drip channel
361 817 211	Rain drip channel
311 817 212	Rain drip channel
361 817 212	Rain drip channel
361 817 367	Rain drip channel (now available as spare parts)
311 863 887	Insulation
311 863 888	Insulation
311 863 889	Insulation (New parts)
311 867 013 A	Trim panel (245)
311 867 014 A	Trim panel (245) (alteration of part No.)
N 10 119 1	Bolt hex. head
N 13 974 1	Tapping screw, countersunk head
N 14 117 2	Screw, fillister head
N 14 212 1	Screw, countersunk head
N 15 422 1	Speed nut
SP 118 A	1 set securing parts
SP 221 A	1 set dust sleeve (New parts)

#### **Section II:**

345 259 199	Drain hose
345 259 200	Drain hose (New parts)
341 700 021 B	Frame
341 705 441	Runners
341 705 442	Runners (modification of seats)
345 800 101	Body, finished
345 800 401	Body bare
345 805 111	Frame – Windshield
345 817 021	Roof
345 817 161	Cross member
345 817 535	Frame
345 817 536	Frame
343 821 805	1 set of mud flaps (New parts)
343 837 289	Housing
343 837 433	Channel (Improvement)
343 837 575	Guide piece
343 837 639	Fastener
343 837 640	Fastener
343 837 643	Bush



343 837 645	Spring washer (now available as spare parts)
345 867 503	Lining – Roof (374), (375)
345 877 071	Sliding roof panel
345 877 201	Plug
345 877 209	Weatherstrip
345 877 213	Weatherstrip
345 877 223	Weatherstrip
345 877 227	Beading
345 877 259	Frame
345 877 279	Retaining channel
345 877 305	Guide
345 877 306	Guide
345 877 355	Guide rail
345 877 356	Guide rail
345 877 357	Tapping screw, countersunk head
345 877 365	Corner piece
345 877 366	Corner piece
345 877 369	Cover channel
345 877 701	Drive gear
345 877 721	Adjusting screw
345 877 725	Cap
345 877 731	Drive shaft
345 877 735	Guide tube
345 877 741	Mounting bracket
345 877 743	Bounded rubber mounting (New parts)
343 881 107 A	Frame
343 881 108 A	Frame
343 881 305 A	Spring core
343 881 375 A	Padding
343 881 455 A	Trim plate
343 881 456 A	Trim plate
343 881 511 A	Frame
343 881 512 A	Frame
343 881 597 A	Spring
343 881 705 A	Spring core
343 881 775 A	Padding
343 881 855 A	Trim plate
343 881 856 A	Trim plate (modification of seats)
345 959 601	Motor
345 959 621	Switch
345 959 675	Carbon brush
N 10 878 1	Screw, fillister head
N 14 262 1	Screw, countersunk raised head (New parts)

**No longer available:**

311 100 021	superseded by: 311 100 021 A
311 101 025	superseded by: 311 101 025 A
311 107 101 0B	superseded by: 311 107 101 CB
311 107 101 0R	superseded by: 311 107 101 CR
311 107 101 0G	superseded by: 311 107 101 CG
311 107 333	superseded by: 311 107 333 A
113 109 019 B	superseded by: 113 109 019 D
113 109 021 B	superseded by: 113 109 021 D
113 109 023 B	superseded by: 113 109 023 D
113 109 025 B	superseded by: 113 109 025 D
113 109 027 B	superseded by: 113 109 027 D
113 109 029 B	superseded by: 113 109 029 D
113 109 031 B	superseded by: 113 109 031 D
113 109 033 B	superseded by: 113 109 033 D
113 109 035 B	superseded by: 113 109 035 D
113 109 309 B	superseded by: 113 109 309 C
311 129 705	superseded by: 311 129 701
311 255 359	superseded by: 113 255 359
311 255 509 B	superseded by: 311 255 509 A
311 255 513	superseded by: 311 255 513 A
311 311 307	superseded by: 311 311 307 A
311 400 025	superseded by: 311 400 025 A
312 400 025	superseded by: 312 400 025 A
341 400 025	superseded by: 341 400 025 A
342 400 025	will not be introduced
311 611 021	superseded by: 311 611 021 A
311 867 013 A (124)	superseded by: 311 867 013 A (245)
311 867 014 A (124)	superseded by: 311 867 014 A (245)

**Section II:**

342 700 021	will not be introduced
344 837 405	will not be introduced
344 837 406	will not be introduced
342 955 325	will not be introduced
342 955 326	will not be introduced
342 955 605	will not be introduced
344 971 011	will not be introduced

**Delete:**

342 415 371	will not be introduced
311 415 565	superseded by: 341 415 565

**Section II:**

311 255 359	superseded by: 113 255 359
-------------	----------------------------

# Supplement 8/62 to Parts List Type 3

## New parts:

311 119 303 D	Cover plate
311 119 304 D	Cover plate (change in production)
311 129 281 A	Gasket
311 129 413 A	Electro-magnetic pilot jet
113 129 413 A	Electro-magnetic pilot jet
311 129 451 C	Diaphragm with push rod (New parts)
113 311 599	Retaining plug (now available as spare part)
341 601 155	Rim embellisher – Road wheel (New part)
311 707 311 B	Bumper (Italy only) (for M 280)
311 809 405	Quarter panel, inner, left
311 809 406	Quarter panel, inner, right
311 809 421	Cover plate, inner – Hinge pillar, left
311 809 422	Cover plate, inner – Hinge pillar, right
311 809 511	Side member, left
311 809 512	Side member, right (to simplify repairs)
361 809 551	Bow – Roof, front
361 809 553	Bow –Roof, center (Now bolted on)
313 877 457	Knob for winder (now available as spare part)
113 919 133	Gasket – Fuel gauge (change in production)
345 937 091	Connector (New part)
311 937 505 A	Fuse box (change in production)
N 17 121 2	Fuse 25 DIN 72 581 (New part)

## Section 2

343 805 591 A	Front panel
343 813 301 A	Rear apron
343 827 025 A	Hood, rear (modified name)
343 813 427	Protective grille (see Workshop Bulletin)

343 853 305 A	Trim molding upper left
343 853 306 A	Trim molding upper right
343 853 307 A	Trim molding lower (now three-part molding)
343 853 311	Sleeve upper
343 853 355 A	Trim molding
343 853 356 A	Trim molding
343 853 357 A	Trim molding (now three-part molding)
141 853 601 B	VW sign
141 853 611	Packing
343 853 615	Seal (change in production)
345 877 231	Water drain hose (New part)
341 957 801	Cable – Speedometer (Improvement)
L 289.4	blue white (New part)

### **No longer available:**

311 119 303 C	superseded by: 311 119 303 D
311 119 304 C	superseded by: 311 119 304 D
311 129 413	superseded by: 311 129 413 A
361 809 557	superseded by: 361 809 551
361 809 559	superseded by: 361 809 553
311 937 505	superseded by: 311 937 505 A

### **Section 2**

343 853 306	superseded by: 343 853 307 A
343 853 356	superseded by: 343 853 357 A
344 857 502	will not be introduced
344 863 107	will not be introduced
344 863 311	will not be introduced
344 863 711	will not be introduced
344 863 712	will not be introduced

### **Delete:**

311 501 201 0B	superseded by: 311 501 201 AB
311 700 041	superseded by: 361 700 041

Jan 9/63

## **Supplement 9/62 to Spare Parts List Type 3**

### **New parts:**

361 800 401 F	Body bare
362 800 401 F	Body bare (also suitable for M 267)
361 809 029 C	Quarter panel
361 809 030 C	Quarter panel
361 809 601 B	Quarter panel
361 809 602 B	Quarter panel
361 845 301 B	Glass – Hinged quarter window
361 847 101 A	Frame
361 847 102 A	Frame
361 847 131 A	Beading
361 847 137	Weatherstrip
361 847 145 A	Weatherstrip (Introduction of hinged quarter window M 268)
113 853 601 B	VW sign
311 853 687	Name (New parts)
311 857 131 A	Lock – Glove compartment lid (not lockable) (now available as spare part)
311 941 125 A	Retainer spring (change in production)
SP 72	1 set of hinged quarter windows (M 268)

### **Section II:**

343 805 019	Panel, outer – Front portion (now available as spare part)
343 823 491	Deflector – Hook (now available as spare part)

**No longer available:**

311 611 021      superseded by: 311 611 021 A  
311 707 021      superseded by: 311 707 111/135 A/136 A  
311 707 031      superseded by: 311 707 311/325 A/326 A  
311 707 031 B    superseded by: 311 707 311 B/325 A/326 A  
311 707 155      superseded by: 311 707 155 A  
311 707 156      superseded by: 311 707 156 A  
361 800 401      superseded by: 361 800 401 F  
362 800 401      superseded by: 362 800 401 F  
311 941 511      superseded by: 311 941 511 A  
N 11 394 1      superseded by: N 13 974 1

**Delete:**

311 012 021      superseded by: 311 012 021 A

**Delete:**

**the Chassis No. in the Text of the following parts:**

311 012 021 A    Tool kit

May 14/63

# Supplement 10/62 to Spare Parts List Type 3

## New parts:

311 255 421	Insulation	361 885 343	Retaining cable (improved heating at rear foot level)
311 255 422	Insulation	K 374 10 B	Leatherette silver beige
311 255 429 A	Muffler – Heater	K 376 10 B	Leatherette silver beige (modified width of length)
311 255 430 A	Muffler – Heater	311 941 141	Adjusting screw (correction)
311 255 455	Spring clip	311 971 011 B	Main harness
311 255 509 C	Heater pipe	312 971 011 A	Main harness
311 255 519	Heater vent	361 971 011 B	Main harness
113 255 529 B	Flap	362 971 011 A	Main harness (change in production)
113 255 541	Knob	N 13 890 2	Tapping screw, cheese head (change in production)
113 255 543 B	Trim cover	SP 127 D	1 set of linings (see Workshop Bulletin M-41)
311 255 545	Rubber seal	SP 136	1 set of cups with pistons
113 255 547	Spring clip	SP 137	1 set of cups with pistons (see Workshop Bulletin B-17)
113 255 549	Spring clip (improved heating at rear foot level)	SP 504	1 set of cylinders 83 mm dia.
311 259 199 B	Water drain hose (improvement)	SP 504 A	1 set of cylinders 83 mm dia. (see circular Spare Parts Service)
311 415 213	Identification ring (see Workshop Bulletin)	D 1 a	Sealing compound (requested by customers)
111 415 431	Nut, slotted (improvement)	<b>Section 2:</b>	
341 415 617	Rubber mounting (prevention of short circuits)	343 255 429 A	Muffler – Heater
361 501 575	Washer (improvement)	343 255 430 A	Muffler – Heater
311 609 237 A	Brake shoe	113 255 499	Rubber seal
311 609 537 C	Brake shoe	343 255 515	Heater vent
311 611 637	Cup	343 259 151 B	Flap – Fresh air control box
361 611 639 A	Cup	343 259 305 A	Fresh air regulator
361 611 655 A	Piston	343 259 375 A	Escutcheon
311 611 657 B	Piston (see Workshop Bulletin B-17)	343 259 379	Button
311 813 133 A	Seal (improvement)	343 259 380	Button (foot level heating, rear)
311 831 421 B	Pin – Hinge	341 700 021 D	Frame
311 831 421 C	Pin – Hinge (new parts)	311 705 221	Cover plate (new part)
311 867 941	Clip (change in production)	341 705 481 A	Kick plate
361 885 031 A	Seat, rear (228)		
361 885 305 A	Spring core		

341 800 101	Body, finished	343 845 252 A	Glass – Vent wing (see Workshop Bulletin A 74)
341 800 401	Body bare	341 853 301	Ornamental plate
341 801 117	Reinforcement	341 853 302	Ornamental plate
341 801 118	Reinforcement	341 853 365	Ornamental plate
341 805 051	Instrument panel	341 853 366	Ornamental plate
341 805 111	Frame – Windshield	343 857 231	Cover plate (new parts)
341 805 345	Cover plate – Hinge pillar	343 857 507 A	Rear view mirror (requested by customers)
341 809 087	Quarter panel	341 863 065	Inner mat (431)
341 809 088	Quarter panel	341 863 066	Inner mat (431)
341 809 405	Quarter panel	341 863 381	Inner mat (431)
341 809 406	Quarter panel	343 863 381 A	Inner mat (431) (new parts)
341 809 407	Reinforcement	343 863 381 B	Inner mat (431) (foot level heating, rear)
341 809 408	Reinforcement	341 863 391	Inner mat (431) (new part)
341 809 415	Support – Top hinge	343 863 391 A	Inner mat (431) (foot level heating, rear)
341 809 416	Support – Top hinge	343 863 391 B	Mat (431) (battery ventilation)
341 809 451	Support – Emergency seat	341 863 392	Inner mat (431) (new part)
341 809 452	Support – Emergency seat	343 863 392 A	Inner mat (431) (foot level heating, rear)
341 813 101	Cross reinforcement (new parts)	343 863 392 B	Mat (431) (battery ventilation)
343 813 101 A	Cross reinforcement (foot level heating, rear)	341 863 395	Inner mat (431)
341 813 107	Support – Emergency seat	341 863 405	Inner mat (431)
341 813 109	Support	341 867 035	Trim panel – Quarter panel, 036, 037
341 813 110	Support	341 867 036	Trim panel – Quarter panel, 036, 037
341 813 111	Floorplate – Luggage compartment, rear	341 871 021	Top frame (ready for fitting), 671, 672, 673, 674, 675, 677
341 813 131	Panel, rear, top (new parts)	341 871 025	Top frame
341 813 191	Reinforcement	341 871 035	Cover – Top, 671, 672, 673, 674, 675, 677
341 813 192	Reinforcement	341 871 041	Boot – Top, 348, 349, 350, 351, 352, 353, 354, 355, 356, 379
341 813 911	Bow, rear	341 871 047	Headlining – Top, 520, 521
341 823 525	Knob (new parts)	341 871 057	Rubber hair matting – Top cover
343 831 735 B	Weatherstrip – Door	341 871 425	Molding – Rear bow
343 831 736 B	Weatherstrip – Door	341 871 431	Molding – Rear support
343 837 649 A	Bolt (see Workshop Bulletin A 74)	341 871 433	Sleeve – Molding
341 845 201	Glass – Door (new part)	341 871 491	Retaining channel – Top cover
343 845 201 A	Glass – Door (see Workshop Bulletin A 74)	341 871 503	Top header – Top frame
341 845 202	Glass – Door (new part)		
343 845 202 A	Glass – Door		
343 845 211 A	Weatherstrip		
343 845 212 A	Weatherstrip		
343 845 251 A	Glass – Vent wing		



341 871 513	Winding gear	341 871 926	Rubber seal
341 871 541	Connecting rod	341 871 929	Insert bar
341 871 551	Locking device – Top	341 871 930	Insert bar
341 871 552	Locking device – Top	341 871 945	Head protection
341 871 571	Retaining bracket – Top catch	341 871 947	Lining (new parts)
341 871 595	Washer	343 881 031 B	Seat, 239, 240, 241, 242, 243, 244, 342, 343, 344, 345, 347
341 871 605	Weatherstrip	343 881 032 B	Seat, 239, 240, 241, 242, 243, 244, 342, 343, 344, 345, 347
341 871 607	Weatherstrip	343 881 107 B	Frame
341 871 613	Cover plate, 036, 037	343 881 108 B	Frame
341 871 701	Frame member – Top	343 881 193	Spring
341 871 702	Frame member – Top	343 881 305 B	Spring core
341 871 723	Guide bar, top	343 881 455 B	Trim plate
341 871 724	Guide bar, top	343 881 456 B	Trim plate (see Workshop Bulletin A-62)
341 871 735	Intermediate bow	141 885 561 A	Retaining hook (new part)
341 871 801	Main bow	341 885 031	Emergency seat, 239, 240, 241, 242, 243, 244, 342, 343, 344, 345, 347
341 871 813	Sleeve	341 885 041	Backrest – Emergency seat, 239, 240, 241, 242, 243, 244, 342, 343, 344, 345, 347
341 871 821	Main guide bar	341 885 599	Retainer – Emergency seat backrest
341 871 822	Main guide bar	K 365 13 B	Leatherette, black
341 871 831	Guide bar	K 371 12 B	Leatherette, ice blue
341 871 851	Guide bar	K 375 12 B	Leatherette, ice blue
341 871 852	Guide bar	E 301	Binding, black-grey (new parts)
341 871 857	Bolt, hex. head	N 13 273 1	Bolt
341 871 871	Rear bow	N 14 234 1	Screw, countersunk head
341 871 901	Snap catch	N 16 215 1	Tubular rivet
341 871 913	Insert bar		
341 871 914	Insert bar		
341 871 921	Insert bar		
341 871 922	Insert bar		
341 871 923	Rubber seal		
341 871 924	Rubber seal		
341 871 925	Rubber seal		

### No longer available:

311 115 451 B superseded by: 311 115 451 C  
311 259 199 A superseded by: 311 259 199 B  
311 259 200 A superseded by: 311 259 199 B  
311 255 720 no longer available  
311 813 133 superseded by: 311 813 133 A  
311 971 011 superseded by: 311 971 011 B  
312 971 011 superseded by: 312 971 011 A  
361 971 011 superseded by: 361 971 011 B  
362 971 011 superseded by: 362 971 011 A  
N 13 890 1 superseded by: N 13 890 2  
N 11 699 2 superseded by: 361 501 575  
K 374 13 B superseded by: K 374 10 B  
K 376 13 B superseded by: K 376 10 B

### Section 2

343 805 591 superseded by: 343 805 591 A  
343 813 301 superseded by: 343 813 301 A  
343 845 211 superseded by: 343 845 211 A  
343 845 212 superseded by: 343 845 212 A  
343 847 341 superseded by: 343 845 211 A/212 A  
343 853 305 superseded by: 343 853 305 A/306 A  
343 853 355 superseded by: 343 853 355 A/356 A  
343 881 031 A superseded by: 343 881 031 B  
343 881 032 A superseded by: 343 881 032 B  
343 881 597 superseded by: 343 881 597 A

### Delete:

311 115 451 B superseded by: 311 115 451 C  
111 721 509 A superseded by: 311 721 509  
N 11 699 2 superseded by: 361 501 575  
N 11 394 1 superseded by: N 13 974 1

### Section 2

343 857 687 superseded by: 343 857 687 A

### At the following part delete in text the Engine No.:

311 115 451 C Oil breather

### At the following part delete in text the Chassis No.:

### Section 2

311 721 509 Lever – Accelerator  
343 857 687 A Cover strip – Instrument panel

May 18/63

# **Supplement 11/63**

## **to Spare Parts List Type 3**

### **New parts:**

311 105 251 D	Pulley – Crankshaft (see Workshop Bulletin)
311 115 123 A	Gear
341 115 605 A	Oil dipstick (change in production)
311 129 641	Wing screw (now available as spare part)
311 255 209	Insulation
311 255 217 A	Mounting bracket (see Workshop Bulletin)
311 255 355 B	Muffler
311 255 356 B	Muffler (change in production)
311 400 025 B	Front axle
312 400 025 B	Front axle (RHD)
341 400 025 B	Front axle
311 401 021 A	Front axle beam
312 401 021 A	Front axle beam (RHD)
311 401 301 C	Needle bearing
311 401 301 D	Needle bearing
311 401 303	Bush
311 401 303 A	Bush
311 405 151 A	Torsion arm
311 405 152 A	Torsion arm
311 405 179 A	Seal (see Workshop Bulletin V 62)
311 405 185	Stop (see Workshop Bulletin V 56)
311 405 361 A	Ball joint
311 405 371 A	Ball joint (see Workshop Bulletin)
311 415 573	Seal (new part)
111 701 259 A	Sleeve (improvement)
311 705 221	Cover plate (new part)
113 721 231 A	Stop (see Workshop Bulletin)
362 857 501 A	Rear view mirror
361 857 502 A	Rear view mirror (to simplify storage)

361 863 879	Lining
361 863 880	Lining (change in production)
311 867 365 A	Beading 744 (improvement)
313 877 307	Guide piece (now available as spare part)
312 881 042	Back 228 (RHD) (improvement)
311 881 193	Spring (now available as spare part)
311 881 305 A	Spring core (change in production)
312 881 706	Spring core (RHD)
312 881 806	Cover 228 (RHD) (improvement)
311 881 931	Pull rod
311 881 947	Retainer (now available as spare part)
311 903 137 A	V-Belt (see Workshop Bulletin)
311 905 250	Retainer
311 905 267	Spacer sleeve (modified mounting)
111 905 429 A	Cap (rubber) (see Workshop Bulletin)
311 911 255	Intermediate bracket
151 947 111 A	Light – Rear luggage compartment
311 949 109	Lens
311 949 109 A	Lens (M 278) (now available as spare part)
113 951 541	Screw, fillister head (change in production)
311 955 463	Hose connection
311 955 465	Seal (now available as spare part)
311 955 749	Thrust washer
311 955 755	Gear
311 955 757	Bearing ball
311 955 779	Gasket
311 955 791	Crank
311 955 813	Armature
311 955 815	Thrust cone
311 955 817	Thrust cone
311 955 821	Washer (single parts for windshield wiper motor)
N 10 336 1	Bolt, hex. head
N 11 166 1	Nut, hex.
N 13 010 1	Stud
N 14 393 2	Stud (new parts)

## Section 2:

### New parts:

343 705 481	Kick plate (foot level heating)
343 847 041	Rear quarter window
343 847 042	Rear quarter window (now supplied with channel)
343 881 306 B	Spring core (new part)
311 953 529	Button (now available as spare part)
343 971 011 A	Main harness (change in production)

### No longer available:

311 105 251 C	superseded by: 311 105 251 D/311 903 137 A
311 115 123	superseded by: 311 115 123 A
341 115 605	superseded by: 341 115 605 A
311 129 767	superseded by: 311 129 767 A
311 255 355 A	superseded by: 311 255 355 B
311 255 356 A	superseded by: 311 255 356 B
311 400 025 A	superseded by: 311 400 025 B
312 400 025 A	superseded by: 312 400 025 B
341 400 025 A	superseded by: 341 400 025 B
311 401 021	superseded by: 311 401 021 A
312 401 021	superseded by: 312 401 021 A
311 405 151	superseded by: 311 405 151 A
311 405 152	superseded by: 311 405 152 A
311 405 345	superseded by: 311 405 185
311 405 346	superseded by: 311 405 185
311 721 231	superseded by: 113 721 231 A
312 721 555	superseded by: 311 721 555
311 809 701 A	superseded by: 311 867 365 A
311 857 501	superseded by: 362 857 501 A
312 857 502	superseded by: 361 857 502 A
361 863 881 A	superseded by: 361 863 879
361 863 882 A	superseded by: 361 863 880
361 863 883	superseded by: 361 863 879
361 863 884	superseded by: 361 863 880
361 863 885	superseded by: 361 863 879
361 863 886	superseded by: 361 863 880
311 881 305	superseded by: 311 881 305 A
311 905 251	superseded by: 311 905 250/267
311 905 263	superseded by: N 10 336 1
311 955 985	superseded by: 113 955 993

**Section 2:**

**No longer available:**

341 705 481 superseded by: 343 705 481  
343 845 301 superseded by: 343 847 041  
343 845 302 superseded by: 343 847 042  
343 847 311 superseded by: 343 847 041  
343 847 312 superseded by: 343 847 042  
343 881 107 A superseded by: 343 881 107 B  
343 881 108 A superseded by: 343 881 108 B  
343 881 305 A superseded by: 343 881 305 B/306 B  
343 971 011 superseded by: 343 971 011 A

**Delete:**

311 129 421 superseded by: 113 129 413 A  
311 129 451 B superseded by: 311 129 451 C/449  
311 847 137 superseded by: 361 847 137  
N 10 071 1 no longer available  
SP 4 A superseded by: SP 504 A

**Section 2:**

**Delete:**

At  
343 863 391 (431) superseded by: 343 863 391 A (431)  
At  
343 863 392 (431) superseded by: 343 863 392 A (431)  
K 385 13 no longer available  
N 10 874 1 superseded by: 113 951 541

# **Supplement 12/63**

## **to Spare Parts List Type 3**

### **New parts:**

361 501 105	Tube – Rear axle (M 267)
361 501 106	Tube – Rear axle (M 267)
311 501 163	Bearing housing
311 501 164	Bearing housing
361 501 189 A	Bumper stop
361 501 190 A	Bumper stop
311 501 283	Ball bearing
311 501 317	Washer
311 501 325	Bolt, hex. head (see Workshop Bulletin)
311 705 453	Runner
311 705 454	Runner (see Workshop Bulletin)
141 711 621 0F	Knob (change in production)
361 813 351	Water drain flap (to simplify repairs)
311 821 805 A	1 set of mud flaps white
361 821 805 A	1 set of mud flaps white (now available as spare part)
311 827 301 C	Hood hinge
311 827 302 C	Hood hinge
311 827 413 A	Hinge stay
311 827 531 A	Cable – Rear hood
311 827 545	Conduit tube (see Workshop Bulletin)
361 827 553	Operation washer
361 863 895	Sound absorber (now available as spare part)
111 941 143 D	Bush, rubber (change in production)
111 012 255	Screwdriver
311 016 025	Spare wheel hub cap with tools (new parts)
N 10 254 2	Bolt, hex. head
N 10 465 1	Bolt, hex. head
N 11 020 2	Nut, hex.
N 12 038 1	Lock washer (improvement)
L 140	Repair primer
L 142	Spotting putty (requested by costumers)
L 180.5	Polishing paste (now supplied in 0.5 kg tins)

### **Section 2:**

343 821 805 A	1 set of mud flaps white (now available as spare part)
343 827 081 A	Gasket (see Workshop Bulletin)
343 881 161 A	Knob – Seat back adjustment (change in production)

### **No longer available:**

311 501 067	superseded by: 111 501 105/311 501 163/361 501 189 A
361 501 067	superseded by: 111 501 105/311 501 163/361 501 189 A
311 501 068	superseded by: 111 501 105/311 501 164/361 501 190A
361 501 068	superseded by: 111 501 105/311 501 164/361 501 190A
361 813 373 A	superseded by: 361 813 351
311 827 413	superseded by: 311 827 413 A
L 180	superseded by: L 180.5

### **Section 2:**

341 823 525	will not be introduced
343 827 081	superseded by: 343 827 081 A
343 881 161	superseded by: 343 881 161 A

### **Delete:**

311 119 517	superseded by: 311 119 513 A
311 863 371	superseded by: 311 863 021
311 863 372	superseded by: 311/312 863 022
SP 4	superseded by: SP 504
LK 41	superseded by: LKL 41
LK 456	superseded by: LKL 456
LOM 62	superseded by: LKM 62

### **At the following part delete in text the Engine-No.:**

311 119 513 A	Cover plate
---------------	-------------

On page 9-11 delete profile H 078  
at Part No. 111 837 219 AR  
(see Parts Department Circular)



Sept 4/63

# **Supplement 13/63**

## **to Spare Parts List Type 3**

### **New parts:**

311 101 381 A	Shim
311 101 385 A	Shim
311 101 387 A	Shim
311 101 389 A	Shim (new parts)
311 105 401 A	Connecting rod
311 107 101 JB	Piston 83 mm dia.
311 107 101 JR	Piston 83 mm dia.
311 107 101 JG	Piston 83 mm dia.
311 107 105 JB	Piston 83.5 mm dia.
311 107 105 JR	Piston 83.5 mm dia.
311 107 105 JG	Piston 83.5 mm dia.
311 107 109 JB	Piston 84 mm dia.
311 107 109 JR	Piston 84 mm dia.
311 107 109 JG	Piston 84 mm dia.
311 107 301 A	Piston ring 83 mm dia.
311 107 305 A	Piston ring 83.5 mm dia.
311 107 309 A	Piston ring 84 mm dia. (see Workshop Bulletin M 49/M 51)
311 129 191 A	Cover (improvement)
311 201 221 A	Feed pipe (see Workshop Bulletin)
311 255 103 A	Heat exchanger
311 255 104 A	Heat exchanger
311 255 145	Protection plate
311 255 146	Protection plate
311 255 149 A	Securing plate
311 255 379 B	Insulation ring
311 255 387 B	Insulation
311 255 388 B	Insulation

311 255 389 B	Insulation
311 255 390 B	Insulation (see Workshop Bulletin)
311 255 475 B	Defroster vent
311 255 476 B	Defroster vent (see Workshop Bulletin)
311 405 375 A	Seal
311 405 377 A	Seal
311 405 387	Retaining ring (now available as spare part)
311 857 121 A	Lid — Glove compartment
312 857 121 A	Lid — Glove compartment (RHD)
311 857 133 A	Striker plate (improvement)
311 857 635 A	Coat hook (now available as spare part)
113 911 123	Grommet
111 911 215 B	Carbon brush
311 911 235	Commutator bearing
113 911 467	Washer
113 911 495	Cap (now available as spare part)
311 953 551	Switch plate
311 953 559	Connection plate (now available as spare part)
SP 29 F	1 set of crankshaft bearings
SP 30 F	1 set of crankshaft bearings
SP 31 F	1 set of crankshaft bearings
SP 32 F	1 set of crankshaft bearings (new parts)
SP 504 B	1 cylinder with piston, rings and piston pin (see Workshop Bulletin M 49/M 51)

**Section II:**

343 700 021	Frame (foot level heating)
K 365 01 B	Leatherette black (amendment of width of length)

### **No longer available:**

311 107 301      superseded by: 311 107 301 A  
311 129 025      superseded by: 311 129 025 A  
311 129 191      superseded by: 311 129 191 A  
311 255 103      superseded by: 311 255 103 A  
311 255 104      superseded by: 311 255 104 A  
311 255 475 A    superseded by: 311 255 475 B  
311 255 476 A    superseded by: 311 255 476 B  
311 405 361      superseded by: 311 405 361 A  
311 405 371      superseded by: 311 405 371 A  
311 611 695      superseded by: 113 611 695 D  
311 857 199      superseded by: 111 837 445  
SP 29 F0          superseded by: SP 29 F

### **Section II:**

341 700 021 B    superseded by: 343 700 021  
341 700 021 D    will not be introduced  
341 705 481 A    will not be introduced  
K 365 13 B        superseded by: K 365 01 B

### **Delete:**

311 129 591      superseded by: 311 129 561  
361 501 067 A    superseded by:  
361 501 105/311 501 163/361 501 189 A  
361 501 068 A    superseded by:  
361 501 106/311 501 164/361 501 190 A

### **Section II:**

343 845 201      superseded by: 343 845 201 A  
343 881 455 A    superseded by: 343 881 455 B

### **At the following part delete in text the Chassis No.:**

343 845 201 A    Glass — Door

1

1

1

1

1

1

# Supplement 14/63

## to Spare Parts List Type 3

### New parts:

311 119 303 E	Cover plate
311 119 304 E	Cover plate (see Workshop Bulletin M 58)
311 129 025 D	Carburetor
311 129 301 B	Main body – Carburetor
311 129 327 A	Atomizer
311 129 405 B	Main jet (see Workshop Bulletin)
311 823 499 A	Rubber stop (see Workshop Bulletin)
311 827 531 B	Cable – Rear hood (alteration of Part-No.)
311 881 165 A	Adjusting cams
311 881 166 A	Adjusting cams
311 881 175	Connecting pipe (now available as spare part)
311 881 945 A	Plug (change in production)
N 14 117 2	Screw, fillister head
L 297.5	colorless
L 298	dark grey
L 299	light grey (Paint – Seat base, see Workshop Bulletin)

### Section 2:

343 813 435	Protective grille
343 813 436	Protective grille (see Workshop Bulletin)

### No longer available:

311 119 303 D	superseded by: 311 119 303 E
311 119 304 D	superseded by: 311 119 304 E
311 129 025 A	superseded by: 311 129 025 D
311 129 301 A	superseded by: 311 129 301 B
311 827 531 A	superseded by: 311 827 531 B
311 881 945	superseded by: 311 881 945 A
311 943 135	superseded by: N 14 117 2

### Section 2:

341 813 191	will not be introduced
341 813 192	will not be introduced
341 813 911	will not be introduced

**Delete:**

311 705 455      superseded by: 311 705 453/454

361 809 601      superseded by: 361 809 601 B

312 857 121      superseded by: 312 857 121 A/111 857 131/311 857 133 A

**Section 2:**

343 881 456 A      superseded by: 343 881 456 B

**At the following part delete in text the  
Chassis No.:**

312 857 121 A      Lid – Glove compartment

Oct 21/63

# **Supplement 15/63**

## **to Spare Parts List Type 3**

### **New parts:**

- 311 101 351 B Cylinder head  
(see Workshop Bulletin M/61)
- 311 105 401 AB Connecting rod (brown)
- 311 105 401 AG Connecting rod (grey)  
(supplied in various weight grades)
- 311 109 301 B Push rod – Valve
- 113 109 427 A Bearing support
- 311 109 443 A Rocker arm  
(see Workshop Bulletin M/61)
- 341 115 451 Oil breather
- 311 115 541 Rubber valve  
(see Workshop Bulletin M/67)
- 311 129 933 Relay shaft
- 311 129 937 Lever
- 311 129 941 Lever
- 311 129 953 Pin  
(see Workshop Bulletin)
- 111 307 113 A Oil seal  
(improvement)
- 311 311 255 Operating sleeve  
(see Workshop Bulletin H/99)
- 311 813 197 Screen plate  
(see Workshop Bulletin)
- 361 863 465 Rubber lining (039) (040)
- 361 863 879 Lining (039) (040)
- 361 863 880 Lining (039) (040)  
(due to introduction of the color anthracite)
- 361 867 501 A Roof lining (374)  
(alteration of Part No.)
- 311 867 933 Insulation  
(see Workshop Bulletin)
- 361 885 753 Rubber lining (039) (040)  
(due to introduction of the color anthracite)

311 885 775 C    Padding  
                  (change in production)

N 11 533 1        Washer A 7.4 DIN 125  
                  (New part)

SP 247            1 set of parts for progressive carburetor operation  
                  (see Workshop Bulletin)

**No longer available:**

311 105 401        superseded by: 311 105 401 AB/AG

311 105 401 A     superseded by: 311 105 401 AB/AG

113 301 205 D     superseded by: 113 301 205 E

361 863 465        superseded by: 361 863 465 (039) (040)

361 863 879        superseded by: 361 863 879 (039) (040)

361 863 880        superseded by: 361 863 880 (039) (040)

361 867 501        superseded by: 361 867 501 A

361 885 753        superseded by: 361 885 753 (039) (040)

311 885 775 B     superseded by: 311 885 775 C